




**USER GUIDE** 

## **Specifications**



| Net weight              | 80g              |
|-------------------------|------------------|
| Size                    | 105*29.5*21.5mm  |
| Battery capacity        | Built-in 3000mAh |
| Input voltage           | 5V/2A            |
| Charging time           | About 3 hours    |
| Adjustable working time | 180s - 360s      |

# **Standard Configuration**



User Manual

(1pcs)





### **Explode View**



# **Operation Instructions**

## 01 Activation Screen

In standby mode, press any button to activate the display.



### 02 Charging

When the system detects that the battery voltage is too low, the battery indicator is flashing to prompt charging. At this time, please charge the device and connect it to a computer or charging adapter with a USB cable to charge it. The battery icon in the screen is blinking, indicating that it is charging, fully back to the main interface, and put out the screen 5 seconds later. Smoking is not supported during the charging.



### 03 Temperature Setting

Press +/- button to increase or decrease temperature, the adjustable temperature range is 200°C-300°C. It is recommended to use 250 degrees as the best smoking temperature.



temperature range is 200°C-300°C

## 04 Smoking Time Setting

In standay mode, press the power button 5 times, the setting smoking time flashes, press the Plus / Minus button to adjust the desired smoking time. After the setting time is completed, the screen will flash 5 times then stop or press the power button once to complete the setting. The desired smoking time can be set from 180 seconds to 360 seconds. Time setting is not supported during smoking.



setting time

#### 65 On/Off

in standby mode, press the power button 3 times within 2 seconds to power on, the device vibrates once and the screen displays the current battery level, the number of lobacco stick, the set smoking time, and the change of current temperature. When the preheating temperature rises to the set temperature, the device will vibrate once again, it is ready for smoking. The device can be morusally tuned off during the smoking, quickly press the power button 3 times, the device vibrates twice with automatic shutdown and displays OVER, then rotums to the main interface, and the acreen is turned off 5 seconds later.



### 06 Working Time

The continuous working time is up to 6 minutes. During the smoking, the screen display the current temperature with real-time change. The device will vibrate once to prompt, when ending smoking, it displays OVER for 3 seconds, then returns to the main interface, and the screen is turned off 5 seconds later.

### smoking countdown



6 minutes maximum

## 07 Smoking Record Clearing

In the standby mode, press the power button 5 times quickly, the smoking time set is flashing, then quickly press the power button 5 times meanwhile, and turn the setting time into the number of tobacco stick in the flashing, at this time, press any bufton once to complete dearing. Smoking record cleaning is not supported during smoking.





----


### 08 Over-temperature Protection

When turning on or using cleaning function, the device displays TOO HOT. Please let the product cool for about 1 minute then reset it.



### 09 Cleaning

There are 2 ways to starting cleaning function. First, in the standby mode, press the power button 8 times continuously, the device will start to automatically clean with 1 vibration, displaying clean.... 5 seconds later and starting the timer, the surface of the heating rod is automatically being cleaned, and the device vibrates once again when the automatic deaning is completed.



Second, after every 5 tobacco sticks are smoked, the system automatically jumps out if the device needs to be cleaned. At the same time, it vibrates 5 times, in the meanwhile, press plusiminus button to switch Y and N, selects Y to display Pls removal of tobacco stick. After confirming the removal of tobacco sticks, press the power button to confirm, enter the cleaning state, select N or no operation for 15 seconds and then return to the main interface. Pay attention to removing the tobacco stick before cleaning.



After the automatic cleaning is completed, to out the heat insulated cover, clean the carb dust in the bottom of heat-insulated cover, a tobacco stick holder with a cleaning brush, cleaning swab etc., and then put the heat-insulat cover back on the device to continue use.







#### Precautions

- The device consists of precision circuits an components. Except for the manufacture please do not attempt to disassemble if. W shall not be liable for any malfunction or accider caused by the private disassembly.
- In order to optimize the smoke and taste, pleas make sure that the totacco stick is dry. Otherwise the smoke and taste will be affected.
- Youths under 18 years old is prohibited to use the device.
- · Beware of falling and crushing

