Getting Started



Turning on

Press and hold the IQOS 3 DUO Pocket Charger button for four seconds, then release. The holder status lights and battery light flash.



Charging the holder

Insert the IQOS 3 DUO Holder into the IQOS 3 DUO Pocket Charger. Close the door to charge.

The holder status light lights up white when charging is complete.


Checking the holder charge



Checking the holder charge

Press the holder button to check the charge.

The number of lights represents the number of sticks the IQOS 3 DUO holder can be used for.



Checking the holder charge with the IQOS 3 DUO Pocket Charger

Insert the IQOS 3 DUO Holder into the IQOS 3 DUO Pocket Charger, then press the Pocket Charger Button to check how many sticks the IQOS 3 DUO holder can be used for.



Checking the holder charge with the IQOS 3 Pocket Charger

Insert the IQOS 3 DUO Holder into the Pocket Charger, then press the Pocket Charger Button to check how many sticks the IQOS 3 DUO holder can be used for.

You may need to update the software for your existing IQOS 3 Pocket Charger. The IQOS 3 DUO holder can be charged before updating the software.




How to use

1. Insert HEATSTICK


Insert the IQOS HEATSTICK into the holder until the line marked on the filter.

IQOS 3 DUO Pocket Charger*




*IQOS 3 DUO is compatible with IQOS 3

IQOS 3 DUO Holder*





Dedicated AC power adaptor



IQOS Cleaning Tool



Dedicated USB cable



IQOS Cleaning Sticks



2. Heat

Press and hold the Holder button until the IOOS 3 DUO Holder vibrates and the lights flash white.



3. Begin use

When the IOOS 3 DUO Holder vibrates twice and the lights stop flashing, your HEATSTICK is ready to enjoy.

Cleaning

CUSTOMER CARE

For the full user guide and Customer Care visit


www.iqos.com

CARE-PLUS

Extended support services for IOOS users

www.igos.com/careplus**

** IQOS CARE PLUS may not be available in your country.



1. Use IQOS cleaning tool


Slide the Cap upward and remove it completely.

Check that the holder has cooled down, then insert the IQOS cleaning tool all the way in and rotate gently.



4. Notification before finishing


When there are 30 seconds remaining, the IQOS 3 DUO holder vibrates twice and the lights flash.



5. Remove HEATSTICK

Slide the cap up and pull the used HEATSTICK stick straight out without twisting.

To continue smoking with a second HEATSTICK, repeat the steps again from Step 1.



Checking the Pocket Charger charge

Press the Pocket Charger button to check its charge.

Troubleshooting



Resetting

Press and hold the Pocket Charger button for about 10 seconds until the status and battery lights flash twice and turn off, then release the button.

When the status and battery lights flash a few times and turn off, the reset is complete.




2. Use IQOS Cleaning Stick

Use the IQOS cleaning stick to

gently wipe the inside of the

Do not apply force, as this may damage the heating blade.

holder.



3. Clean the cap

The cap is cleaned in the same way, wiping with the cleaning stick from the top and bottom.

Please clean your IQOS regularly for optimum enjoyment.



If lights flash white twice, try one of the following:

1. Wait until the product is inside its operating temperature range (0°C - 50°C).

2. Insert the IQOS 3 DUO into the Pocket Charger and wait until it has charged completely.



Light blinks red

Please reset the IOOS. If the light continues to flash, please contact IQOS Customer Care.

49.G791