


X7-Heat not burn



User Manual

Product description





Start using

(1) Preparation for use
Insert a cigarette rod through the entrance





(2) Enable device



(3) End use

Notice : Do not press the function button during use. If you want to stop using it, long press the function button 2S



(4) Remove the cigarette rod



Rotate the cigarette rod left and right more than 3 times to remove the rod


Cleaning and care

(1) Clean with a cleaning brush

(2) Clean with a cleaning rod

Notice : Do not use brute force to avoid equipment damage

(3) Heat cleaning



Quickly press the Power button 5 times within 2s to start the device


The LED indicator flashes orange for 90s and is automatically cleaned

After the cleaning is finished, the LED light is off + vibration


Notice : Heating and cleaning are the processes of burning foreign matter by heating. At this point, the temperature of the heater is very high, so please do not let the heater touch anything

Solve the problem


(1) cigarette rod cannot be inserted into the device



Check if there is any smoke stick residue in the cigarette rod insertion opening




If the residue is left, separate the Heat-insulated Cap and the rod bar from the device




Remove residue

(2) Device cannot start



LED light is red, power is low, please charge




LED light is red and flashing, fault has occurred, please reset




The LED light is orange and flashes. The device is overheated and can be used normally after cooling.

Notice : Restricted use when continuous for 15 minutes and more than 3 times


(3) Reset device



Press and hold the Power button 3S, even if the vibration occurs after 2S, continue to press



During the reset process, the LEDs are blue, light blue, orange, and flashing 5S.



The reset is completed. The LED is light blue and lights up 1S and vibrates.

Please Notice

(1) The device operates in units of 4 minutes and 20 seconds. The indicator lights up automatically when you press the Power button or link the USB cable.

(2) Charging Tips : LED indicator lights up when charging, LED indicator goes off when fully charged (Can use about 20 cartridges when fully charged)

(3) Keep equipment and components out of reach of children

(4) When using the device, the device will continue to heat up after removing the rod. Please grow , Press the 2 second start button to turn off the power

(5) Please clean up after the device has cooled down completely.

(6) If the equipment is not used for a long time, the voltage will drop due to its own discharge phenomenon. Please complete the charging before using

(7) Do not ignite smoking on the cigarette rod

(8) Smoke rods are sold separately from equipment

(9) After using a cigarette rod, mottle or discoloration will appear on the rod, which is normal

(10) Disposal method: This equipment contains lithium-ion batteries. Disposal is to comply with relevant laws and regulations such as resource conservation and promotion of reuse

Made in China

